



Note: First and last deck board screwed to Boundary Joists.
 Other deck boards attached to joists with EB-TY® Premium Fasteners

SIMPSON Strong-Tie®
 EB-TY Installation — Side View